

Shoji Lamp Installation

1) First locate the lattice panel marked on the “BACK” side of the lamp. The panel can be removed from the lamp in the upright position. If the lamp is too tall to, then lean your Shoji Lamp on a chair or place it directly on the floor with the side marked “BACK” on the chair or floor.



2) Locate the white clasp(s) that hold in the back Lattice Panel. There may be one or two clasps per end.



3) Rotate the clasps 90 degrees as shown on the top and bottom of the panel.



4) Carefully remove the panel as shown.



5) Add or change bulbs. Only use 60, 75 or 100 watt compact fluorescent lamps. **The use is incandescent bulbs will void any warranty and may cause a fire hazard.** Due to the size of the newer compact fluorescent bulbs it may be necessary to install the top bulb closest to the back panel after the back panel has been reinstalled.



6) Reinstall the panel and rotate the clasps to secure the panel.

If there are any questions about this procedure, please contact:

Sebago Furniture
88 Rolling Hill Drive
Naples, ME. 04055
207 – 591 – 4215

WEB: www.sebagofurniture.com

EMAIL: rob@sebagofurniture.com